

Catastrophic Centrifuge Failure



What happened?

The workers were processing slurry from a storage tank that was used to store shaker screen runoff. A vac truck was used to direct feed the centrifuge through the centrifuge feed pump. As the second load was finished, the centrifuge operator went to the PLC controls to wind down the machine from its operating speed. At this point, the centrifuge made a loud noise and began to vibrate. Immediately after the loud noise, the centrifuge back drive motor, gearbox and drive shaft were ejected from the centrifuge stand, falling to the ground.

Why did it happen?

It was determined that the most likely cause of failure was gradual and repetitive overloading of the conveyor drive as a result of a solids blockage at the solids end.

This overload and blockage produced sufficient axial loading that stretched the conical and the cylindrical section bolts, creating an uneven gap in the mating surfaces due to the "Power Screw" forces shown at the solids end. These forces can become large in magnitude and cause many components to overload, however, in this instance, it caused a significant imbalance of the conical section, causing the cascading failures of the centrifuge assembly.



What did they learn?

A storage tank is utilized to store shaker screen drill fluid runoff that collects in the cuttings tank, which is located directly underneath the shaker slide. This fluid is later sucked out of the cuttings tank by a vac truck and stored in the storage tank until it is processed and added back into the main drilling fluid. When the fluid/slurry is sucked out of the cuttings tank, it is common that drill cuttings and heavy solids are mixed in at that point. Typically, the slurry from the storage tank is run over the shakers, which removes heavy solids, but that did not occur in this case.

Ask yourself or your crew:

- Could something like this happen on our worksite?
- Have the fluids/slurry that are going to be processed through the centrifuge been screened?
- Do the operators and the supervisors directing the use of centrifuges understand the need for screening slurry to protect the centrifuge?



Submit your Safety Alert

Help industry by sharing lessons learned from an incident. Submit your Safety Alert.

SHARE AND COLLABORATE

Energy Safety Canada (ESC) works collaboratively with industry to share information aimed at helping companies of all sizes improve safe work performance.

DISCLAIMER

Use of this document or any information contained herein is at the user's sole risk. ESC makes no representations and assumes no liability. For further information on these restrictions, go to https://www.energysafetycanada.com/Legal

COPYRIGHT/RIGHT TO REPRODUCE

Copyright for this document is held by Energy Safety Canada, 2024. All rights reserved. Energy Safety Canada encourages the copying, reproduction and distribution of this document to promote health and safety in the workplace, if Energy Safety Canada is acknowledged. However, no part of this publication may be copied, reproduced or distributed for profit or other commercial enterprise, nor may any part be incorporated into any other publication, without written permission of Energy Safety Canada.